
PS2 user manual—Chinese and English

将 PS2 手柄的接收器和舵机控制板 用 7 根杜邦线按照下图中的方式连接起来(注意顺序)

English: Use 7 DuPont lines/cable to connect PS2 receiver and servo control board together. Pls connect it as the following picture show. Do not connect it wrong.



连接之后如果供电正常, 手柄接收器上的2个灯都会常亮。


English: After connecting, if the power supply is normal, the PS2 receiver 's 2 indicate light will be lighting.

配置手柄

打开 RIOS_USC 电脑软件,进入设置。

English: Open RIOS_USC software, enter into to set up.

(下载:http://dl.torobot.com/down/rios_usc.exe)



然后在右侧 PS2 手柄按钮附近的输入框中输入按键需要执行的动作组命令。(格式: #1GC2, 1G是第一个动作组, C2是循环执行一次)

English: Pls input the Action group number in the white blank (#1GC2, 1G means first action group, C2 means execute two times)

设置完了,按下"OK"确定设置。 然后重启舵机控制板(给舵机控制板重新上电) 然后就可以用手柄的按键控制动作组了。

English: After finishing seting up , press "ok" . Then Restart the servo controller board.

<mark>备注:</mark> Remark:

手柄接收器和控制板正常连接之后,如果供电正常,手柄接收器上面的指示灯会全亮,如果是闪烁状态,就需要检查手柄是否供电或者是否打开电源开关。

English: PS2 receiver and servo control board connect well, if power supply normal, the indicate bulb on PS2 receiver will be light up. If the indicate bulb flashing, pls check whether the PS2'S power supply is ok or check whether the power switch is turn on.

2. 手柄具有睡眠功能,如果发现手柄上面的指示灯全灭,可能是进入睡眠,可以按下手柄中间的 START按钮恢复。

English: PS2 has sleeping function, if the indicate bulbs turned off, pls press "start" to make PS2 work again.